16 July 2017 HVAC



However, the germs are not killed. They remain as viable particles in the filters until the filters are removed and disposed of. This means that the filters must be replaced frequently to maintain their expected performance.

As soon as a new filter is put into action, it starts to collect particles and clog and the performance begins to decline. Filter replacement must be carried out with the utmost care to prevent any collected, still viable particles from being released back into the cleanroom, where they could re-pollute the air and compromise the results or work beeing carried out in the facilities.

The disposal of the used filters is highly regulated, complex and adds costs. An additional consequence of the filter replacement work is that sensitive work samples must be removed from the cleanroom, which means that not only are operations interrupted but after the filter replacement there is a waiting time to have the air once again clean enough for the operations to restart. This cleanroom downtime causes considerable disruption to operations and increases operational expense.

Technology has moved on, however, and today new equipment is available, that has been independently tested since 2001, and proven to perform in 20 or more countries for various customers including cleanrooms.

Genano technology enables all contaminating particles and gases to be removed from cleanrooms on a permanent basis – while killing any bacteria and viruses rather than simply capturing them. The term "all" alludes to the fact that the new machines will kill and remove all viable particles down to 3nm, something that filters alone cannot do. Below 3nm, the particles lose their molecular structure and therefore cease to exist.(would like more explanation?)

The process that kills those particles is ionisation. Inside the machine is a central core which emits negative ions into the incoming air, charging all the particles negatively and because the internal wall



PURIFYING AIR IN LABS AND CLEANROOMS

For facilities that want cleaner air but not the expense of complex HVAC and HEPA filters, **Jarmo Kesanto**, Director, KSG Health, highlights a new technology that can remove volatiles and viable particles down to 3 nanometers in size

of the machine is infused with positive ions, it catches the particles due to their polarity and renders them lifeless.

There are a significant number of harmful particles at the lower end of the size spectrum – between 3 to 30nm – that can be eliminated and removed, along with the larger-sized particles. As well as removing nano-sized particles from the cleanroom air, in comparison to the removal of filters, there is no risk of them escaping back into the cleanroom.

The technology was developed in Finland over 25 years ago, by the Finnish state technology research centre, university and occupational health authority.

Since commercialising the completed invention, the machines have been operating globally and have seen application in many different types of laboratories, hospitals (operating theatres, isolation rooms, intensive care units), IVF clinics, as well as in the fast growing market of educational classrooms (see applications panel opposite).

Since the introduction of Genano

machines into UK laboratories, figures showing up to an 80% reduction in bacterial contamination levels, in comparison with the existing methods, have been recorded.

LEANROO

There is no structural alteration needed to accommodate the machines and they make few demands on the environment.

The Genano portable "plug and play" machines are on wheels, enabling them to be wheeled into the facility. To fill the washing liquid container, they are simply plugged into the electrical socket and switched on. Using the same amount of electricity as a 90-watt light bulb, they have a very low impact on the facility's carbon footprint.

Maintenance and costs

Compared to the regular and elaborate requirements for filter replacement, the entire maintenance ritual for the Genano technology comprises refilling the washing liquid container, on average once a month or once a quarter, depending on the machine size selected. The units automatically carryout a rinse on a weekly

CLEANROOM TECHNOLOGY



Top left: The machine can simply be wheeled into the room and plugged into the electric supply Right: Maintenance for Genano technology comprises refilling the washing liquid container on average once a month or once a quarter, depending on the machine size selected



basis and leave no toxic waste.

The annual service required includes power cleaning the unit inside and replacing the carbon plate, which collects the gases (also removing smells from the room). No particles are stored in the carbon plate.

The annual service takes one person approximately two hours and the work leaves no toxic waste. For servicing, the unit can be rolled out from the cleanroom so there is no interruption of the operations.

With traditional filter-based solutions for cleanrooms structural HVAC work needs to be implemented during the initial facility build. The HVAC systems are usually built into the fabric of the cleanroom structure and often are linked to the HVAC system of the entire building.

These indirect costs of building work are usually not included in the actual air purification costs, and normally fall into another budget/expense line rather than the cleanroom operational budget. Therefore, the operation budgets for filter based air purification solutions do not reflect the real costs.

Size matters

One of the challenges that many cleanroom users currently face is the limited measurement technology available for recording the smallest, nano-sized particles contaminating the air. There are sophisticated devices on the market able to do the job but those devices are very expensive, and most investment budgets are tight.

Consequently, there is a gap in the market that can be filled by service providers able to help in dealing with such nano-size particles.

CONTACT Jarmo Kesanto, Director KSG Health Ltd Jarmo.kesanto@ksghealth.com +44 (0) 203 302 6367 www.ksghealth.com

EXAMPLES OF IN-USE APPLICATIONS

Removing contamination from within a research centre Scottish Universities

Environmental Research Centre (SUERC) had problems with air quality and contamination. With Genano, the total amount of VOCs in the air went down to one third, solving the contamination issue.

Air purification in a molecular diagnostics company

Mobidiag develops and manufactures molecular diagnostic kits for detecting human pathogens.

The challenge was removing PCR amplification products (DNA) from the air which could otherwise contaminate products, leading to false positives. New cleanrooms were built with Genano and the laboratory has now two ISO 6 compliant areas.

Reducing contamination in a PCR production company

For Finnzymes laboratories, a company involved in DNA research, analytics and diagnostics production, Genano prevents airborne particles from spreading to products and processes in open vials.

Protecting haematology patients in Polish regional hospitals

Genano has delivered a total of over 150 air purifiers to Polish hospitals responsible for haematology and oncology. They are used to protect immunosuppressed patients after bone marrow transplantation.

Protecting new life in fertility clinics

Oocytes (egg cells) and embryos are very sensitive to air contamination before implantation. Genano air purifiers are used at a top fertility clinic to further purify HEPA-filtered air in premises where in vitro fertilisation (IVF) is carried out.